

folkblues Mark-II

ultimo

aero reed

音配列表

No.1210 / 1810 / 2010 音配列表 全 14 キー (12 キー+Low F & High G)

A^b
(G[#])

ヘンド								D ^b	D	G ^b
吹音	A ^b	C	E ^b	A ^b	C	E ^b	A ^b	C	E ^b	A ^b
	1	2	3	4	5	6	7	8	9	10
吸音	B ^b	E ^b	G	B ^b	D ^b	F	G	B ^b	D ^b	F
ヘンド	A	D	G ^b	A		E				
			D ^b	F						
			E							

D

ヘンド								F	A ^b	C
吹音	D	F [#]	A	D	F [#]	A	D	F [#]	A	D
	1	2	3	4	5	6	7	8	9	10
吸音	E	A	C [#]	E	G	B	C [#]	E	G	B
ヘンド	E ^b	A ^b	C	E ^b		B ^b				
		G	B							
			B ^b							

A

ヘンド								C	E ^b	G
吹音	A	C [#]	E	A	C [#]	E	A	C [#]	E	A
	1	2	3	4	5	6	7	8	9	10
吸音	B	E	G [#]	B	D	F [#]	G [#]	B	D	F [#]
ヘンド	B ^b	E ^b	G	B ^b		F				
		D	G ^b							
			F							

E^b
(D[#])

ヘンド								G ^b	A	D
吹音	E ^b	G	B ^b	E ^b	G	B ^b	E ^b	G	B ^b	E ^b
	1	2	3	4	5	6	7	8	9	10
吸音	F	B ^b	D	F	A ^b	C	D	F	A ^b	C
ヘンド	E	A	D ^b	E		B				
		A ^b	C							
			B							

B^b
(A[#])

ヘンド								D ^b	E	A ^b
吹音	B ^b	D	F	B ^b	D	F	B ^b	D	F	B ^b
	1	2	3	4	5	6	7	8	9	10
吸音	C	F	A	C	E ^b	G	A	C	E ^b	G
ヘンド	B	E	A ^b	B		G ^b				
		E ^b	G							
			G ^b							

E

ヘンド								G	B ^b	D
吹音	E	G [#]	B	E	G [#]	B	E	G [#]	B	E
	1	2	3	4	5	6	7	8	9	10
吸音	F [#]	B	D [#]	F [#]	A	C [#]	D [#]	F [#]	A	C [#]
ヘンド	F	B ^b	D	F		C				
		A	D ^b							
			C							

B

ヘンド								D	F	A
吹音	B	D [#]	F [#]	B	D [#]	F [#]	B	D [#]	F [#]	B
	1	2	3	4	5	6	7	8	9	10
吸音	C [#]	F [#]	A [#]	C [#]	E	G [#]	A [#]	C [#]	E	G [#]
ヘンド	C	F	A	C		G				
		E	A ^b							
			G							

F^{and} LF

ヘンド								A ^b	B	E ^b
吹音	F	A	C	F	A	C	F	A	C	F
	1	2	3	4	5	6	7	8	9	10
吸音	G	C	E	G	B ^b	D	E	G	B ^b	D
ヘンド	G ^b	B	E ^b	G ^b		D ^b				
		B ^b	D							
			D ^b							

C

ヘンド								E ^b	G ^b	B
吹音	C	E	G	C	E	G	C	E	G	C
	1	2	3	4	5	6	7	8	9	10
吸音	D	G	B	D	F	A	B	D	F	A
ヘンド	D ^b	G ^b	B ^b	D ^b		A ^b				
		F	A							
			A ^b							

F[#]
(G^b)

ヘンド								A	C	F
吹音	F [#]	A [#]	C [#]	F [#]	A [#]	C [#]	F [#]	A [#]	C [#]	F [#]
	1	2	3	4	5	6	7	8	9	10
吸音	G [#]	C [#]	F	G [#]	B	D [#]	F	G [#]	B	D [#]
ヘンド	G	C	E	G		D				
		B	E ^b							
			D							

D^b
(C[#])

ヘンド								E	G	B
吹音	D ^b	F	A ^b	D ^b	F	A ^b	D ^b	F	A ^b	D ^b
	1	2	3	4	5	6	7	8	9	10
吸音	E ^b	A ^b	C	E ^b	G ^b	B ^b	C	E ^b	G ^b	B ^b
ヘンド	D	G	B	D		A				
		G ^b	B ^b							
			A							

G^{and} HG

ヘンド								B ^b	D ^b	F
吹音	G	B	D	G	B	D	G	B	D	G
	1	2	3	4	5	6	7	8	9	10
吸音	A	D	F [#]	A	C	E	F [#]	A	C	E
ヘンド	A ^b	D ^b	F	A ^b		E ^b				
		C	E							
			E ^b							